



# HOLDSTER™ N1321 Bag For use with 2-Up, Chopped or Shorty SwitchBlade™ Windshields

### Parts List

Holdster Bag	1
Internal Frame, Polycarbonate	1

### Bag #682

Screw, M6 x 20	2
Washer Flat, 1/4"	2

### Tools

- #2 Phillips Screwdriver
- 10mm Wrench

### Care

Your Holdster windshield bag is manufactured from quality high grade artificial leather which is mildew and UV protected. Holdster material is weather tested to over 1 year of Ultra Violet exposure. Holdsters can be easily cleaned with a water damp cloth. You may also use a leather or plastic polish on the product.

### INSTALLATION

Remove the two center screws from the horizontal section of the windshield frame. Screws will not be re-used. From the front of the Windshield, insert the supplied M6 x 20 Screws through the bag, internal polycarbonate Frame and Washers. Secure with original Nuts. Re-tighten the Screws and Cap Nuts to 10-14 in. lbs. (1.1 - 1.6 Nm), torque pressure. **Figure 1.**



Figure 1

National Cycle, Inc. P.O. Box 158 Maywood, IL 60153-0158 USA 708-343-0400 Fax: 708-343-0625

E-mail: [info@nationalcycle.com](mailto:info@nationalcycle.com) [www.nationalcycle.com](http://www.nationalcycle.com)

10-114101-000 05/05 Page 1 of 1



# HOLDSTER™ N1321 Bag For use with 2-Up, Chopped or Shorty SwitchBlade™ Windshields

### Parts List

Holdster Bag	1
Internal Frame, Polycarbonate	1

### Bag #682

Screw, M6 x 20	2
Washer Flat, 1/4"	2

### Tools

- #2 Phillips Screwdriver
- 10mm Wrench

### Care

Your Holdster windshield bag is manufactured from quality high grade artificial leather which is mildew and UV protected. Holdster material is weather tested to over 1 year of Ultra Violet exposure. Holdsters can be easily cleaned with a water damp cloth. You may also use a leather or plastic polish on the product.

### INSTALLATION

Remove the two center screws from the horizontal section of the windshield frame. Screws will not be re-used. From the front of the Windshield, insert the supplied M6 x 20 Screws through the bag, internal polycarbonate Frame and Washers. Secure with original Nuts. Re-tighten the Screws and Cap Nuts to 10-14 in. lbs. (1.1 - 1.6 Nm), torque pressure. **Figure 1.**



Figure 1

National Cycle, Inc. P.O. Box 158 Maywood, IL 60153-0158 USA 708-343-0400 Fax: 708-343-0625

E-mail: [info@nationalcycle.com](mailto:info@nationalcycle.com) [www.nationalcycle.com](http://www.nationalcycle.com)

10-114101-000 05/05 Page 1 of 1