

Attention




Special notes and cautionary measures which can prevent damage to the accessory or motorcycle.

Note:



Tips for facilitation of operation, control and adjustment, as well as maintenance work.



TOOLS REQUIRED:

- 4mm Hex Key
- 5mm Hex Key



Right and left side of motorcycle is determined while sitting on the bike.

PARTS LIST

<u>Index</u>	<u>Description</u>	<u>Qty.</u>
1	Windscreen, Quantum® Hardcoated Polycarbonate	1

INSTALLATION



Retain all fasteners and front plates, as they will be reused.

1. Remove the 4 screws holding the front plates and gasket. **(4mm Hex Key)**
2. Remove the 2 screws holding the stock windshield. **(5mm Hex Key)**
3. Place VStream Windshield into position on motorcycle. Install windshield using the 2 stock screws. Tighten the screws firmly. **Do not over tighten. (5mm Hex Key) Figure 1**
4. Place gasket on outside of windshield, place cover and secure with the stock screws. Tighten the screws firmly. **Do not over tighten. (4mm Hex Key) Figure 2**

CARE AND CLEANING

Wash with a clean soft cloth, plenty of warm water and, if necessary, a non-abrasive soap such as dishwashing liquid. Flannel or soft chamois make good cleaning cloths.

Do not clean polycarbonate in hot sun or high temperatures. Do not clean the screen with glass cleaners. Do not use rain protective products on the screen. The solvent action of the alcohol in these products will destroy the screen. Do not allow brake fluid, alcohol, or strong solvents to contact the screen.



Figure 1




Figure 2



Replace Gasket