

Thank you for purchasing a ZTechnik product. Read these instructions carefully and thoroughly before beginning work. Dealers if installing this windshield for a customer please give them this manual. It contains information needed to properly maintain and use this product.



Attention:

Special notes and cautionary measures which can prevent damage to the accessory or motorcycle.



Note:

Tips for facilitation of operation, control and adjustment, as well as maintenance work.



Figure 1



Figure 2



Figure 3

©2005 National Cycle, Inc.

708-343-0400

CONTENTS OF KIT

Description Item

Z2242

1 Windshield

Qty.

1

TOOL REQUIRED:

3mm Hex Key 10mm Wrench

PREPARATION



Some R 1200 GS models have front bushings isolating the hole of the stock windshield. If you have these bushings, they will be re-used in the installation of your new ZTechnik Windshield. All other stock hardware will be re-used.



Pay attention to the *acorn nut and the top hat* located inside the side brackets. Do not let these parts fall to the inside of the motorcycle. Figure 1.

1. Remove the stock windshield. Figure 1 and 2.

-17100

The Cap assemblies attached to the windshield are left and right sided. Do not mix. Figure 3.

2. Remove the Cap Assemblies from the original windshield.

ZTechnik PO Box 158 Maywood, IL 60153-0158 USA Fax: 708-343-0625 / www.Z Technik.com / e mail: info@Z Technik.com Page 1 of 2

-1710/

10-118521-000 Rev B 10/10

10





Figure 4 Showing Exterior Bushing




Figure 5




Figure 6

A CHARACTER A

ZTechnik 3-Year Limited Warranty

INSTALLATION



1. Install the Cap Assemblies to the ZTechnik Windshield. Mate the two pieces, noting the position of the three tabs. Figure 4.

2. Install the Windshield at the left and right sides of the motorcycle. Top Hat and Acorn Nut go to the inside of the bracket. **Figure 5.**

3. Using original bushings and fasteners install windshield to stock hardware at front. **Figure 6.**


4. Firmly tighten all hardware. There will be a slight gap between the Top Hat and the Acorn Nut at the sides.

The Acorn Nut is designed to "bottom-out" when tightened. It prevents the Top Hat Assembly from being removed when adjusting the windshield rake angle.

MAINTENANCE

To clean the screen, wash with a clean soft cloth, plenty of warm water and if necessary, a non-abrasive soap such as dishwashing liquid. Flannel or soft chamois make good cleaning cloths. **Paint, glue residue or grease removal:** Moisten cotton with Naphtha or Turpentine followed by a wash as above. National Cycle Shield Wash[™] makes a good daily cleaner and comes with a handy travel size bottle. N1401 Shield Wash is safe for helmet visors.

Do not clean polycarbonate in hot sun or high temperatures. Do not clean the screen with glass cleaners. Do not use rain protective products on the screen other than National Cycle brand Rain Zip® (Part No. N1410). Do not allow brake fluid, alcohol, or strong solvents to contact the screen.





Register your windshield on Line at: www.ZTechnik.com

ZTechnik hereby warrants to the original registered owner of a ZTechnik polycarbonate windshield for a period of three years from the date of purchase against breakage. This limited warranty is expressly limited to the replacement of the polycarbonate windscreen. This limited warranty does not include scratches, coating failure, cosmetic wear and tear, replacement of hardware, or any consequential damages or expenses including labor cost of installa-

tion, removal and/or replacement, inconvenience, inbound freight expenses or damage to any other component of the motorcycle or any other accessories. Certain chemicals, generally known as acidic hydrocarbons, are known to cause polycarbonate damage and will not be covered under this limited warranty. Please refer to the cleaning instructions supplied with all ZTechnik windshields.

Visit www.ZTechnik.com for further details are call or write ZTechnik / PO Box 158 / Maywood, IL 60153 / 708-3430400

